



Component


2Bow
QTY

3Bow
QTY


4Bow
QTY

2 Bow Tubes		2		
3 Bow Tubes			2	
4 Bow Tubes				2
Crossbars		2	3	4
Canopy		1	1	1
Thumb Screw		2	2	2
Deck Mount		2	2	2
Stainless Steel Saddle		4	4	4
Self Tapping Screw		12	12	12
Bolt SS316		4	6	6
Straps with Stainless Steel Hook & Webbing Adjust		6	8	8
Hexagonal Nut SS317		4	4	4
Storage Boot		1	1	1


ASSEMBLY INSTRUCTIONS




1. Check and open bimini box carefully



2. Take out full set bimini parts




3. Lay fabric flat upside-down, sleeves up.




4. Insert the crossbars into the fabric sleeves.




5 & 6. Snap the frame into the crossbars via the connectors, then slide into the fabric



7. Snap connector




8. Secure each straps with bolts and nuts as showed.



9. Measure and confirm the marks for the deck mounts and saddles.



10. Drill and secure the deck mounts and saddles.



11&12. Flip the bimini and place it on deck mounts, and tighten all straps to complete your bimini.

