



## REUSABLE FLY TRAP

### DIRECTIONS FOR USE

1. Unscrew lid and remove foil pouch.
2. Tear open pouch at tabs and drop inner packet into trap.
3. Add water to fill line. (Water will dissolve packet.)
4. Replace top securely.
5. Hang or place trap outside near a fly source.
6. Attractant will activate within 2-5 hours, creating an odor attractive to flies.
7. Wash hands with soap and water.
8. Empty trap and replace attractant when trap dries out or becomes full, or after 30 days - whichever comes first.



### HELPFUL HINTS

Weather conditions affect fly activity and trap effectiveness. In hotter temperatures, place traps in shade.

In cooler temperatures, flies will be more active where it is warmer, so place traps in sun-exposed areas.

**STORAGE:** Store in a cool, dry, well-ventilated location out of reach of pets and livestock.

**DISPOSAL:** Deposit in trash for collection. Wash hands with soap and water.

rescue.com

 /rescuepestcontrol

 @rescue