# Small Animal Heated Pad™

Care & Instructions

Made in China
K&H Manufacturing, LLC
Colorado Springs, CO
www.khmfg.com | (719) 591-6950

Thank you for purchasing K&H Manufacturing's Small Animal Heated Pad™. When used correctly, your Small Animal Heated Pad™ should provide years of hassle free warmth for your pet. Your Small Animal Heated Pad™ is intended for use indoors and outdoors and is perfect for garages, porches, barns and animal shelters and cages. The Small Animal Heated Pad™ is designed for use with animals only.

**WARNING:** This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock or fire which could cause serious bodily injury.

### **USE INSTRUCTIONS**

# Read all instructions carefully. This is an electrical product, pay special care to IMPORTANT SAFEGUARDS.

- Place directly on a hard, flat surface in the home or inside a doghouse or kennel. Area chosen should be a sheltered area out of direct rain or snow.
- Plug into 110-120 volt AC outlet. Allow one to two hours for the SMALL ANIMAL HEATED PAD™ to warm. The unit will feel slightly warm to the touch. When an animal lies on it, the pad will reach a maximum temperature of approximately 104 degrees F. The built in thermostat will automatically regulate the temperature.
- After initial warm-up, your SMALL ANIMAL HEATED PAD™ will feel cooler to the touch. This is the intension for energy efficiency. When you pet lies upon the bed, it will warm to a cozy, pet pleasing temperature even in the coldest of weather.
- Testing your SMALL ANIMAL HEATED PAD<sup>TM</sup>. Place a blanket, pillow or other insulating object over part of your Lectro-Kennel<sup>TM</sup> bed. After a few minutes, place your hand under the insulating object to experience the warmth your pet will enjoy.
- To store your SMALL ANIMAL HEATED PAD™, unplug, clean, and store pad when not in use.
- When used with young puppies, convalescent pets, or when pad is used in a warmer environment, an optional LECTRO-TEMP CONTROL<sup>TM</sup> may be used to reduce the pad temperature to the exact temperature desired.
- Save these instructions for your use.



Small Animal Heated Pad™

## IMPORTANT SAFEGUARDS

### For household Use Only\*

\*The heated pad is an electrical device and must only be operated inside an enclosure such as a porch, shed, barn, dog house, or cat house.

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- To protect against electrical hazards, **DO NOT** immerse cord, plug, or appliance in water or other liquid.
- **Close supervision is necessary** when used by or near children.
- **ALWAYS** unplug from outlet when not in use.
- **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any way. **RETURN** all malfunctioning appliances to the factory for examination.
- **DO NOT** use appliance for anything other than its intended use.
- DO NOT PUNCTURE PLASTIC HOUSING FOR ANY REASON.
- For use with 110-120 volt AC **ONLY.**
- DO NOT cover your SMALL ANIMAL HEATED PAD™ with blankets or materials other than a fleece K&H SMALL ANIMAL DELUXE HEATED PAD COVER. Other coverings may not allow heat to radiate properly and could cause pad failure.
- When placing the pad in an enclosed area, be sure pad covers no more than half of the floor space so your pet has the option of sleeping on or off the SMALL ANIMAL HEATED PAD™.
- When used outside your home, this unit must be plugged into a properly grounded electrical outlet rated for outdoor use. If you do not have a properly grounded outlet, contact a certified electrician to have one installed.
- Always make sure the cord exits your pet's enclosure. Keep cord out of shelter.

#### Care Instructions:

Your SMALL ANIMAL HEATED PAD™ may be cleaned with a damp cloth when unplugged. The unit may be plugged in when the plug is thoroughly dry.

#### K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with dated proof of purchase or original date receipt. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.