




RedStone Tabletop Fireplace Heater


FAST USER GUIDE

Model No. FEJ-16A

SKU No. 1245463



PRODUCT DIAGRAM



1. The main power switch is located on the Rear cover and switch with flame effect
2. Heat switch – One switch for low heat setting (750 Watts)
3. Heat Switch - Two switches for high heat setting (1500 Watts)

OPERATING YOUR HEATER

Once the stove has been properly assembled and connected to an electrical outlet, it is ready to operate:

1. Main Power:

The main power switch (#1) is located on the Rear cover. Press the switch with flame effect.

2. 750W:

For low heat function - Press 750W switch (#2) while the main power switch (#1) is opened.

3. 1500W: (Both 750W Switches)

For high heat function - Press both two 750W switches (#2) (#3) while the main power switch (#1) is opened.