



# AXTF REPLACEMENT TRANSFORMER

## ■ INSTALLATION

The replacement transformer recharges your gate batteries, and it works with all GHOST CONTROLS® Automatic Gate Opener systems.

- UL Listed
- Plugs into 120V/60Hz AC Outlet
- 18VAC Output
- Automatically internally resets if output wires are accidentally shorted together
- Must be located within 1000' of gate system controller
- Must be enclosed in weatherproof box if installed in outdoor location

### NOTE:

A 2 stranded, 16-gauge low voltage cable is required to connect the transformer to the control box.

### WARRANTY:

GHOST CONTROLS® AXTF Replacement Transformer are warrantied for 18 months with proof of purchase. An additional 6 month warranty is available at NO COST if you register your item within 30 days of purchase on [www.ghostcontrols.com/register](http://www.ghostcontrols.com/register). See warranty terms on [www.ghostcontrols.com/warranty](http://www.ghostcontrols.com/warranty).

For more information on GHOST CONTROLS® Automatic Gate Openers and Accessories please visit our website at [www.ghostcontrols.com](http://www.ghostcontrols.com).