



OWNER ' S MANUAL


Schwinn® Quad Steer Wagon

¥ ASSEMBLY
¥ OPERATING
¥ ADJUSTMENTS
¥ MAINTENANCE
¥ WARRANTY

*In the interest of safety, make certain that you read
and understand all information and instructions
included with and pertaining to this product.*



Personal Care from **PACIFICCYCLE**



Congratulations on your new purchase!
Our Service Department is dedicated to your satisfaction with Pacific Cycle and its products.
For questions regarding performance, assembly, operation, parts or returns, contact the experts at Pacific Cycle directly by calling toll free

1-800-626-2811

8:00am - 5:00pm Central Time

Monday thru Friday

Or by email at

customerservice@pacific-cycle.com

**DO NOT RETURN THIS ITEM TO
THE STORE. PLEASE CALL PACIFIC
CYCLE FOR ASSISTANCE.**

Rules for Children

WARNING: THERE ARE NO BRAKES IN A WAGON.

Wagons are not intended to be ridden as "go carts". Do not ride in any wagon without someone holding the handle.

To avoid accidents, teach children good riding skills with an emphasis on safety from an early age.

1. Always wear a properly fitted helmet.
2. Do not play in driveways or the road.
3. Do not ride on busy streets.
4. Do not ride at night.
5. Obey all the traffic laws, especially stop signs and red lights.
6. Be aware of other road vehicles behind and nearby.



The Consumer Protection Safety Commission advises that the riding of small wheel diameter toys at excessive speeds can lead to instability and is not recommended.

Children should be made aware of all possible riding hazards and correct riding behavior before they take to the streets

- Do not leave it up to trial and error.

A SPECIAL NOTE FOR PARENTS

This toy is intended for use by small children. As a parent or guardian, you bear the responsibility of ensuring the safety of your child. To make sure this toy is used safely, a responsible adult must supervise any child playing with it. This includes allowing it to be used only where and when it is clearly safe for a small child to do so and making certain that it is in good repair and secure operating condition.



Schwinn Quad Steer Wagon Assembly

Tools needed:

- 14mm wrench
- 10mm wrench
- Phillips screwdriver
- Pliers
- Hammer





Parts list:

- 1) Wagon bed
- 2) Chassis spine
- 3) Front axle assembly (note 2 extra holes in axle frame)
- 4) Rear axle assembly (no extra holes in axle frame)
- 5) Steering linkage rod
- 6) Right handle frame
- 7) Left handle frame
- 8) Handle assembly
- 9) Wheels (x4)
- 10) Small parts bag:
- 11) Spine bolts, (with washers and nuts) (x2)
- 12) Main pivot bolts (with washers and castle nuts) (x2)
- 13) Cotter pins (x6)
- 14) Axle pivot clevis pins (x2)
- 15) Handle mounting bolts (with washers and nuts) (x2)
- 16) Rear wheel spacers (x2)
- 17) Axle wave washers (x4)
- 18) Wheel snap caps (x4)

Before beginning assembly, unpack and inspect all parts listed above. If any parts are missing or damaged, DO NOT RETURN WAGON TO DEALER. Please call 1-800-626-2811 for replacement or missing parts.




Schwinn Quad Steer Wagon Parts Diagram



Step 1.

Hand tighten all bolts first. This will make aligning parts for assembly much easier.


Attach chassis spine to wagon bed using (2) #11 spine bolts. Hand tighten only.



Step 2.

Remove plastic caps from either end of chassis spine. Slide #3 front axle assembly into position, by inserting the axle through the slot in the chassis spine, and aligning the center pivot hole with the wagon bed hole. **IMPORTANT:** make sure that the steering tabs are faced to the inside of wagon. Insert (1) #12 main pivot bolt through bed and axle. Install washer and castle nut and hand tighten only.


Repeat for #4 rear axle assembly, making sure that steering tabs are facing towards inside of wagon.



Step 3.

Replace chassis spine snap cap and align holes in axle and chassis spine. Insert a #14 pivot clevis pin through chassis spine, cap and axle. Install washer and #13 cotter pin through hole in clevis pin. Using pliers, bend cotter pin slightly out to lock it in place (after final assembly, cotter pin will be bent completely to secure, bending slightly now, will allow disassembly if any mistakes are made.)


Repeat for rear axle assembly.



Step 4.

Insert #5 steering linkage so that both ends fit into steering tabs on front and rear axles. Insert a #13 cotter pin through hole in steering linkage and bend slightly.

Repeat for rear steering tab.



Step 5.


Install #6 right handle frame by sliding over right front axle and aligning holes in handle frame and front axle assembly. Insert a #15 handle frame mounting bolt and hand tighten the washer and nut.

Repeat for left side.



Step 6.





Loosen and remove Phillips screw and cap from #8 steering handle assembly. Press one cap over steering handle frame and check that holes are aligned. Position steering handle between steering handle frames with red push button facing towards top of wagon (faced down as you are working upside down). Insert other steering handle cap and bolt through handle frame, handle and into other handle cap. Tighten screw with Phillips screwdriver until handle will stay at any angle that you move it to. (If screw is too loose, handle will slip and slowly rotate down to the ground.)



Step 7.


Now go back and tighten all bolts and adjust steering tension.

- a) Tighten spine chassis bolts securely with 14mm wrench.
- b) Tighten main pivot castle nut with wrench until axle assembly is snug and requires some pressure to rotate. Insert a #13 cotter pin through castle nut and bolt and bend securely with pliers. Repeat for rear main pivot bolt.
- c) Bend cotter pins in steering clevis pins and steering linkage rods securely.
- d) Tighten steering frame bolts securely using 10mm wrench.



Step 8.

Install (1) #16 rear wheel spacer on rear axle and #17 wave washer.




Step 9.

Place one wheel on rear axle after spacer and wave washer. Using hammer, carefully hammer on a #18 wheel snap cap. Wheel should turn freely but have no extra play.

Repeat for other rear wheel.

Repeat for both front wheels, by installing (1) wave washer per side (no spacer needed), wheel and snap cap.




Step 10.

Your Schwinn[®] wagon is now assembled and ready to roll. Please inspect your Schwinn[®] wagon often to keep bolts tight, cotter pins properly installed and look for signs of any damaged or defective parts.

Cared for properly, your Schwinn[®] wagon should last for a lifetime of fun.

Features:

- 1) Telescopic handle - To change the length of the handle of your Schwinn[®] wagon, gently press the red button located on the handle extension, and pull or push handle in or out to desired length. The handle has four possible lengths. Once at its longest position, do not continue to pull on handle, or damage may occur. Always make sure that the locking button has engaged fully before pulling on wagon.
- 2) Folding handle - For easier storage, your Schwinn[®] wagon handle can be folded underneath. Simply lift wagon from front end and rotate handle underneath wagon completely.
- 3) Quad steering - Only Schwinn[®] wagons have our unique "Quad steering" feature. The steering is automatic. Just pull the wagon where you want it to go. It will automatically follow your line. Unlike traditional 2 wheel steering wagons, the quad steer is great at maneuvering around objects, and has the smallest turning radius of any wagon on the market.

- 
- 4) Durable powder coat finish - Schwinn[®] wagons are coated with a durable thick powder coat finish, which will withstand years of abuse. Although your Schwinn[®] wagon is strong, it is susceptible to rust if there are any deep gauges in the finish. It is recommended to touch up scratches with a similar color paint, or clear paint before rust can develop.
 - 5) Air tires - To make your Schwinn[®] wagon ride as smoothly as possible, it is equipped with air filled tires. The air pressure should be checked at the beginning of each season of use and periodically through out the year. Follow the recommended air pressure on the side of the tire for the best ride possible.

LIMITED WARRANTY AND POLICY ON REPLACEMENT PROCEDURES AND RESPONSIBILITIES

Your purchase includes the following warranty which is in lieu of all other express warranties. This warranty is extended only to the initial consumer purchaser. No warranty registration is required. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The entire wagon frame is guaranteed against faulty materials and workmanship for as long as the initial consumer purchaser has the wagon, subject to the condition of the warranty listed below. If wagon frame failure should occur due to faulty materials or workmanship during the guarantee period, the wagon frame will be replaced. For frame replacement under this Pacific Limited Warranty, contact us, stating the nature of the failure, model number, date received and the name of the store from which the wagon was received, at the address given on the following page. Wagon frames must be returned for inspection at customer's expense.

All other parts of the unit, except Normal Wear Parts, are warranted against defective materials and workmanship for a period of 1 year from the date of purchase by the initial consumer purchaser, subject to the Terms and Conditions of the warranty listed below. (If failure of any part should occur during the warranty period, the part will be replaced for you if the failure was due to faulty materials or workmanship). All warranty claims must be submitted to the address below and must be shipped prepaid and accompanied by proof of purchase.

Any other warranty claims not included in this statement are void. This especially includes installation, assembly, and disassembly costs. This warranty does not cover paint damage, rust or any modifications made to the wagon. Normal Wear Parts are defined as grips, tires, tubes and cables. These parts are warranted to be free from defects in material and workmanship as delivered with the product. Any claim for repair or replacement of Normal Wear Parts (grips, tubes, tires, cables, brake shoes and saddle covering) and missing parts must be made within thirty (30) days of the date of purchase. The warranty does not cover normal wear and tear, improper assembly or maintenance or installation of parts or accessories not originally intended or compatible with the bicycle as sold. The warranty does not apply to damage or failure due to accident, abuse, misuse, neglect or theft. Claims involving these issues will not be honored.

Your wagon has been designed for general transportation and recreational use, but has not been designed to withstand abuse associated with stunting and jumping. This warranty ceases when you rent, sell, or give away the wagon, ride with more than one person or use the wagon for stunting or jumping.

(continued)

This warranty does not cover ordinary wear and tear or anything you break accidentally or deliberately.

It is the responsibility of the individual consumer purchaser to assure that all parts included in the factory-sealed carton are properly installed, all functional parts are initially adjusted properly, and subsequent normal maintenance services and adjustments necessary to keep the wagon in good operating condition are properly made. This warranty does not apply to damage due to improper installation of parts or failure to properly maintain or adjust the wagon.

NOTICE: Specifications subject to change without notice.

PACIFIC CYCLE LLC
4730 East Radio Tower Lane/PO Box 344
Olney, IL 62450
Call Toll Free 1-800-626-2811
Monday -Friday 8:00 a.m. to 5:00 p.m. Central Time
Customerservice@pacific-cycle.com

