

CONTACT INFORMATION

CUSTOMER SERVICE
M-F 9:00AM-5:00PM CST
Phone:(636) 680-9189 or (855) 965-5310
Email:cs@discoverhomeproducts.com

MADE IN CHINA

PRODUCT MANUAL

3 TIER VERTICAL GARDEN MODEL#:WQ-3TP SKU#:1273212

Instruction Guide
















PARTS LIST

READ AND SAVE THESE INSTRUCTION

Please read instructions carefully and identify all the parts before assembly.


- Caution: Small parts like bolts, may pose a choking hazard to young children keep out of reach of small children.

Part A - 2 Pcs	Part B - 2 Pcs	Part C - 2 Pcs	
 (109x5x2.5cm)		 (32.5x5x2.5cm)	
Side Long Frames	Middle Leg Frames	Top Leg Frames	
Part D - 2 Pcs	Part E - 3 Pcs	Part F - 6 Pcs	
 (39.5x5x2.5cm)	 (14.5x6x1.5cm)	 (23.8x12.5x1.5cm)	
Lower Leg Frames	Middle Braces	Side Braces	
Part G - 6 Pcs	Part H - 3 Pcs	Part I - 2 Pcs	
 (91x14.5x1.5cm)	 (91x10.5x1.5cm)	 (83x3x3cm)	
Side Frames	Bottom Frames	Support Frames	
Part J - 2 Pcs	Part K - 4 Pcs	Part L - 15 Pcs	Part M - 1 Piece
			
Bolt Sets (M4x30mm)	Bolt and Washer Sets (M6x40mm)	Screws	Driver


ASSEMBLY INSTRUCTIONS

IMPORTANT:

Please check that all parts are included before assembling.
For ease, separate all contents by part number.




Step 1: Inserted Side Braces (F) into Side Frames (G) faces inside as shown in Figure 1.




Step 2: Inserted Middle Braces (E) and Bottom Frames (H) into Step 1 as shown in Figure 2.

ASSEMBLY INSTRUCTIONS




Step 3: Connect Middle Braces (E), Side Braces (F) and Bottom Frames (H) by using screws (L) as shown in Figure 3. **(Repeat this two times)**




Step 4: Connect Middle Leg Frames (B) and Side Long Frames (A) by using Bolt Sets (J) as shown in Figure 4. **(Repeat this on other side)**

ASSEMBLY INSTRUCTIONS



Step 5: Connect Top Leg Frames (C), Lower Leg Frames (D), Support Frames (I) and Side Long Frames (A) by using Bolt and Washer Sets (K) as shown in Figure 5.



Step 6: Place assembly from Figure 3 into assembly from Figure 5 as shown in Figure 6.

Now please enjoy your new 3 Tier Vertical Garden.

WARRANTY

90 day Limited Warranty

All furniture sold is warranted to the original purchaser against defects in workmanship and materials. If a product fails during the first 90 days from date of purchase under the terms of our limited warranty, please contact customer support. Manufacturer reserves the right in the case of discontinued or out of production models, to replace with an item of similar quality.

Wood

This product is made of solid wood. Color variations, knots, small-pitted areas, gum and mineral deposits, and other marks of nature are normal and guarantee that you have purchased genuine solid wood furniture. You should expect a natural variation in wood grain and coloration between like pieces. Water or other liquids must never be left standing on wood surfaces.

WARRANTY

Finishes

The finish is warranted against blistering, peeling, or cracking. Fading resulting from exposure to elements, chemicals, and spills are not covered. Scratches and chips due to normal wear and use are not covered.

Note: You must retain original receipt to obtain warranty!

Exclusions

- Damage caused by acts of nature.
- Wind damage.
- Failure caused by unreasonable, unanticipated or abusive use.
- Warranty will be void without original receipt.
- Warranty does not cover any commercial use of this product.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.