








Iconic Pet Adjustable Double Dinner (U- design) Assembling instructions

Parts:


- a. Bowl fastener (2) b. Bowl holder (2) c. U-shaped bar d. Stand e. Base Knob(2) f. Bowl(2)



Instructions:




Step 1: Slide bowl fasteners(a) and bowl holders(b) onto each side of U-shaped bar(c). Make sure all the knobs of the fasteners and holders are on one side of the U-Shaped bar.



Step 2: Align the U-shaped bar(c) with holes on the stand(d), insert Base Knobs(e) and tighten them.

Step 3: Adjust the bowl holders(b) to desired height and tighten the knobs of the Bowl Holders(b).



Step 4: Insert the bowls(f) into the bowl holders(b) and tighten the knobs of the bowl fasteners(a).



Your pet's adjustable double dinner (U- design) is ready for use.