


Repair Parts



Repair Parts

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	3	49449	1" Plug	22	1	44566	Torsion Spring
2	17	47189	1/4" Nylock Hex Nut	23	1	47063	5/32" Cotter Pin
3	10	43088	Washer, 5/16"	24	2	45705	Spacer
4	1	47141	1/4" Nylon Wing Nut	25	2	47963	Flange Bearing
5	2	1543-69	Nylon Washer	26	1	28611	1/2" Axle
6	1	27322BL1	Flow Control Mounting Bracket	27	1	6-1057BL3	Frame Assembly
7	1	24858	Adjustable Stop	28	1	69209	Gearbox Assembly
8	1	44950	1/4-20 X 3/4" Carriage Bolt	29	1	43093	Cotter Pin
9	1	43848	Control Arm Grip	30	1	2-819BL3	Leg Tube
10	1	24856BL1	Flow Control Arm	31	2	45702Y	Wheel
11	1	42347	Torsion Spring	32	6	43648	1/4 X 1-1/2" Hex Bolt
12	2	43661	1/4-20 X 1" Hex Bolt	33	1	45428	Flow plate
13	6	1509-69	1/4-20 X 1-3/4" Hex Bolt	34	1	2-118	Slide Gate Bracket
14	3	44101	5/32" Cotter Pin	35	1	2-551BL3	Lower Handle Tube
15	1	45431	Control Rod	36	2	44482	Handle Grip
16	1	28662BL3	Handle Tube	37	1	44589BL3	Short Handle Tube
17	1	48934	Hairpin Agitator	38	1	23753	Gate Slide Angle Bracket
18	1	45433G	Hopper Assembly	39	2	C-9M5732	Rivet, Pop 3/16 SD 66 BS ZY
19	2	28486BL1	Support Angle		1	3-373	Owner's Manual
20	1	45504	Impeller		1	3-374	Quick Start Guide
21	3	R19171616	Large Washer, 17/32"				