


# Hey! Play! Toy Acoustic Guitar


## Item #80-GD-3510



### **Adjusting the Strings:**

Adjust the sounds of the guitar strings by making sure all the strings are connected through the turning peg. Rotate each turning peg on the back of the guitar to either tighten or loosen it based on the desired sound wanted for each string.

Be careful not to tighten the strings too tightly or they will snap.



### **Playing the Guitar:**

Use your dominant hand to tap the strings on the main part of the guitar with your fingers. Use your other hand to hold the top of the guitar. You can play around with different sounds by tightening and loosening the strings, and by pressing down on certain strings with your other hand.

Warning: Not suitable for children under 3 years of age because of removable parts and long strings, which can cause choking and strangulation hazards. Remove all packaging before giving to children to play.

Made in China.