



Bare Ground Sprayer Use Instructions

Directions for Use:

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

For Outdoor Use Only

Shake Well Before Using

DO NOT USE FLAMMABLE LIQUIDS IN ANY SPRAYER!

How to use your sprayer

1. Detach wand from retaining clip and pull the hose from the storage compartment.
2. Turn the pump handle counterclockwise to make sure the pump is tight and push the black and yellow pop-up pressure indicator completely down. (See Figure 1)
3. Turn the pump handle clockwise one-quarter turn to release the handle and pump the sprayer until the black and yellow pressure indicator pops up about an inch. That's your signal you are ready to spray. (See Figure 2a and Figure 2b)
4. Turn the pump handle counterclockwise one-quarter turn to secure the handle for carrying and begin spraying by pushing the lever on the spray handle down.
5. Select the desired spray pattern by rotating the black nozzle at the tip of the wand. Tighten for a straight stream and loosen the tip for a misting spray effect. See (Figure 3)
6. For continuous spraying, push the spray lever down and slide forward to lock. Pull back to release. (See Figure 4)
7. When finished spraying, slowly turn the pump handle clockwise to loosen and release pressure, then turn back counterclockwise to re-tighten the handle.
8. To store the sprayer, push the hose back into the storage compartment and attach the wand to the retaining clip.



(Figure 1)



(Figure 2a)



(Figure 2b)



(Figure 3)



(Figure 4)

Refilling the sprayer

1. When empty, refill the tank with Bare Ground liquid ice melt.
2. Turn the pump handle clockwise to un-tighten and remove the pump.
3. Follow the instructions of the ice melt label directions to refill.
4. Put the pump back into the sprayer and turn the pump handle clockwise to re-tighten.

For additional Information please see our website at: www.bareground.com

Or scan our QR code.

