

INSTRUCTION



CHICKEN COOP HEATER & BROODER


Model No.1299682

CAUTION: Read all instructions and warnings before Operating!
SAVE THESE INSTRUCTIONS! READ ALL INSTRUCTIONS!

▼ HEATER CONFIGURATION


The Producers Pride Chicken Coop Heater and Brooder has been designed to stand in a vertical and horizontal position. Simply insert the provided legs as seen below into the bottom or end of the heater panel to best fit your coop needs.

NOTE: To avoid damage to the legs, do not use excessive pressure to push legs into panel.



two Legs for Heater

The Producers Pride coop heater / brooder has been designed for an optional wall mount configuration. To install using this method, locate the mounting screw holes on the back of the heater (see illustration below for reference.). Measure the distance from the center of each hole. Next, locate a solid mounting surface on the wall and mark location using the measurements taken from the mounting screw holes on the back of the panel. Install two screws or nails and then hang panel on screws or nails.




▼ BROODER CONFIGURATION

When using as a brooder, four separate legs have been provided in kit.

NOTE: Each leg for the brooder configuration has three levels providing a height adjustment to meet your different needs. Select the height that best suits the size of your baby chicks and your coop or containment requirements. The height for baby chicks should allow them to walk under the brooder heater without touching the heater panel.

As shown below, determine the best height for your baby chicks and coop or containment requirements and then insert one leg into each corner of the panel. Make sure all four legs are inserted at the same height level so that panel sets flat and level.




Four Legs for Brooder

As an optional brooder configuration, the Producers Pride coop heater / brooder has been designed to hang as shown in the illustration below.

NOTE: Chains are not included with this kit.

To use in this configuration, purchase a small chain and connect one end to all four corners of the panel as shown in the illustration below. Connect the other ends of all four chains to a single connector. Then connect to a secure location above the area where you want to use the brooder heater.

NOTE: Height adjustment will need to be made by adjusting the length of the chain.




CAUTION:

Mount vertically. Do not use directly on floor or in horizontal position. Allow heater to cool before touching or moving.

HEAT CONTROL:

The heater has a special in-cord switch allowing you to select Heater(200W) or Brooder (40W) to choose. This switch is LIT when the unit is ON. The middle position is OFF.



SAFETY HEAT DISPLAY:

The Heater has a heat-sensitive indicator at the front surface to show when the surface is warm. The heat sensitive indicator turns **RED** when warm and disappears when cool.

CLEANING:

Unplug unit and wipe with a damp cloth.

IMPORTANT: READ BEFORE USE

CAUTION : This appliance is designed for use ONLY with 110/120volt power supply. Do not use the heater with 220/240volt electric supply such as is common in UK, Europe & other countries outside the USA.

This appliance has a polarized plug. One blade is wider than the other. To reduce risk of electric shock, this plug is intended to fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

WARNING : Take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to suitability or fitness of these devices for any specific application. While product includes an over temperature regulator, misuse may cause failure, damaging the product, mounting surface or work area. Use in a dry area; avoid exposure to moisture. Mount free from materials that hinder the transfer of heat. Do not drape or cover product with any material. Always allow heat to escape. Protect from puncture. Turn off when not in use. Use caution as you would with any hot product, especially if you have any issues with loss of feeling in the areas affected by the heat.

Distributed by: TRACTOR SUPPLY COMPANY.

5401 VIRGINIA WAY BRENTWOOD, TN 37027

For customer support

Call 1-888-376-9601

MADE IN CHINA

1299682

WWW.TractorSupply.com

05/2018