



# MOBILE TASK LIGHT

Model # 00173

## OPERATION

### TURNING ON/OFF

Press power button located on top of main body to turn ON. **Lightly press & HOLD to turn OFF.**

### CHOOSING MODES

Press power button to cycle through modes: High > Med > Low > Strobe

Mobile Task Light remembers the last mode used after turning off and will return to that mode when powered back on.

### BATTERY LEVEL INDICATION

Each time The Mobile Task Light is turned off the power button will blink to indicate the battery level as follows:  
4 blinks = 75-100% / 3 blinks = 50-75% / 2 blinks = 25-50% / 1 blink = less than 25%

Mobile Task Light will continue to blink 3 times and pause when battery is critically low until the battery is dead

**NOTE: The Mobile Task Light will immediately shut off when battery is dead. The light will not dim as the battery gets low.**

### CHARGING

1) Plug the micro-USB cable into the micro-USB port of the Mobile Task Light 2) plug the other end of the cable into a USB wall charger\*, USB car charger\*, or any other USB charging device\* (such as a computer).

\*Not included. \*Charger output of 1A to 2A is recommended to charge the Mobile Task Light. To prevent battery damage charger output should NOT exceed 2A.

- - Power button blinks while charging then solid glow when fully charged.

*\*\*Please recharge a stored unit every four months to maintain optimum performance of the lithium-ion batteries and maximize charging levels. Damage to unmaintained battery is not covered by warranty.*

### SAFETY

- **WARNING:** This product contains high intensity LED devices. To prevent permanent eye damage, do not stare into the light beam at close range.
- To prevent battery damage use power charger with output of 1A to 2A to charge the Mobile Task Light.

