




Instructions & Warnings Inside
Las instrucciones y advertencias en el interior



MPP Mine Light Directions:

Aim light in any direction by placing on flat surface or stick to any metal surface.

Spot light and Red Signal Light

(A red push button switch is located on one of the twelve protrusions)

- 1) Press the red switch (1 time) to turn white light on low.
- 2) Press switch again (2 times) to turn white light on high.
- 3) Press switch again (3rd time) to activate red blinking signal.
- 4) Press switch again (4th time) to turn lights off.

Changing the Batteries:

- 1) Look for "Open-Arrow Icon" located on battery cap (fig. 1)*
- 2) Twist in the direction the of the arrow a quarter turn (counter clockwise) and then pull off the cap.
- 3) Tilt downward to allow battery cartridge to slide out, tap lightly in hand if necessary (fig. 2).
- 4) Replace all three AAA batteries. (note (+) and (-) directions)
- 5) Insert cartridge back into the body by aligning the arrow with the notch (fig. 3).
- 6) Replace the cap and twist clockwise a quarter turn.

***Attempting to remove the cap with the ON/OFF switch will damage/break the light.**

WARNING: (1) Choking Hazard. Small parts, not for children. (2) Do not dispose of batteries in fire - may explode or leak. (3) Do not mix old and new batteries, do not mix alkaline with non-alkaline batteries. (4) Magnets could affect pacemaker/ICD devices. Keep at least 12 inches (30 centimeters) away.

Dirija la luz en cualquier dirección colocando en una superficie plana o en cualquier superficie de metal.

Spot de luz y señal de luz roja

(encender /apagar)

(Un interruptor rojo se encuentra en uno de los doce salientes)

- 1) Presione el botón rojo (1 vez) para encender la luz blanca en el bajo.
- 2) Presione el interruptor de nuevo (2 veces) para encender la luz blanca en lo alto.
- 3) Presione el interruptor de nuevo (3^a vez) para activar la señal roja intermitente.
- 4) Presione el interruptor de nuevo (4^a vez) para encender las luces apagadas.

Cómo cambiar las pilas:

- 1) Busque "abierto Flecha Icono", situado en la tapa de la batería (fig. 1) *
- 2) Twist en la dirección de la flecha un cuarto de vuelta (hacia la izquierda) y después retire la tapa.
- 3) Inclinación hacia abajo para permitir cartucho de la batería en su deslizamiento, toque suavemente en la mano si es necesario (fig. 2)
- 4) Sustituir las tres pilas AAA. (Nota (+) y (-) las instrucciones)
- 5) Inserte el cartucho nuevo en el cuerpo haciendo coincidir la flecha con la muesca (fig. 3).
- 6) Vuelva a colocar la tapa y gire en sentido horario un cuarto de vuelta.

*** El intento de retirar la tapa con el interruptor ON / OFF dañar o romper la luz.**

ADVERTENCIA: (1) Riesgo de asfixia Las partes pequeñas, no son aptas para niños. (2) No incinere las baterías ya que podrían explotar o filtrarse. (3) No mezcle pilas viejas y nuevas, no mezcle pilas alcalinas con pilas recargables no alcalinas. (4) Los imanes pueden afectar el funcionamiento de marcapasos o dispositivos de cuidados intensivos. Mantenga por lo menos a 30 centímetros (12 pulgadas) de distancia.