



AIR CONDITIONER

5,000 BTU WINDOW AC



WINDOW AC FEATURES

- Adjustable temperature settings
- Slide-out washable filter
- 2-speed rotary dials
- 2-way air direction control
- Window mounting kit

CHOOSING

THE RIGHT SIZE AIR CONDITIONER FOR YOUR ROOM

1 MEASURE AREA OF THE ROOM

CALCULATE ROOM SIZE
room length x room width = sq. ft.

2 MATCH ROOM SIZE WITH CORRECT BTUs

ROOM SIZE (sq. ft.)	BTUs	
150	10' x 15'	5,000
250	15.5' x 16'	6,000
350	17.5' x 20'	8,000
450	18' x 25'	10,000
550	22' x 25'	12,000
700	25' x 28'	15,000
1,000	31.25' x 32'	18,000
1,500	37.5' x 40'	25,000
2,000	40' x 50'	28,500

3 CONFIRM WINDOW OPENING SIZE

MEASURE WINDOW OPENING IN INCHES
for thru-the-wall units, confirm & measure wall opening size in inches

4 CHECK ELECTRICAL REQUIREMENTS

OUTLET CONFIGURATIONS

DETERMINE IF YOUR CIRCUIT IS ADEQUATE

5PMC5000	
UPC CODE	8-42149-02853-4
COOLING CAPACITY (BTU)	5,000
COVERAGE (sq. ft.)	100-150
EER	11.1
ENERGY STAR RATED	No
FAN SPEEDS (Cool/Fan)	2/2
AMPS	4.0
WATTS	454
DECIBELS (Hi/Lo)	55/51
WINDOW WIDTH (Min./Max.) (in.)	23/36
WINDOW HEIGHT (Min.) (in.)	13
UNIT DIMENSIONS (WxHxD) (in.)	16 x 12 ^{1/4} x 13 ^{1/4}
PKG. DIMENSIONS (WxHxD) (in.)	18 x 15 x 15 ^{1/2}
STUFFING QTY. (20'/40'/40' HQ)	468/918/1050
WEIGHT (Net/Gross) (lbs.)	35/40
REFRIGERATION	R32
OUTLET CONFIGURATION	15 AMP 115V



PA/SS_5PMC5000/11202018

5401 Dansher Road
Countryside, IL 60525

866.996.9255
630.323.2301

www.perfectaire.us
support@perfectaire.us