

1388527 1 Gallon Pump Sprayer **Polyethylene Sprayer Instructions**

If you have any questions or concerns, or missing parts, **Do not return sprayer to the store!**

Call our hotline: 1-800-9-SPRAYER (1-800-977-7293)

Common maintenance questions: www.hdhudson.com/FAQS

FOR YOUR SAFETY

This sprayer operates with liquid under pressure. Failure to observe cautions and follow instructions for use and maintenance can cause tank, hose or other parts to become corroded, weakened, and/or burst. This can result in serious injury or property damage from forcible ejection of parts or high-pressure discharge of spray material. Do not use any flammables or boiling liquids in this sprayer as it is not designed nor intended for such use. Some spray materials can ignite or explode. Do not spray in an enclosed space, near an open flame such as found in a bbq grill or water heater, near an electric motor or open switch, or any source of heat. Do not smoke while spraying. Use of flammables could result in serious injury or property damage from unintended ignition or explosion. Do not use any caustics or acids in this sprayer, since these can damage or weaken the sprayer and its parts, resulting in serious injury or property damage. Keep out of reach from children and pets. Always read and follow directions on the spray material container, including the need for protective clothing. Before using your sprayer, thoroughly inspect both inside and outside of the sprayer and do not pressurize sprayer if tank, hose or other parts appear to be damaged, discolored, brittle, excessively soft or loose. Do not pressurize with any mechanical device such as an air compressor, since this can create dangerous pressure and bursting of parts and result in serious injury. Wear long-sleeved shirt, pants, gloves, goggles or similar protective clothing when spraying. PROP 65 WARNING: This product contains one or more chemicals, including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

LIMITED WARRANTY

H. D. Hudson Manufacturing Company warrants to the original consumer purchaser of this product at retail that it is free from problems in materials and workmanship for the period of 1 year from the original date of purchase. This warranty does not apply to damage to the product resulting from accident, misuse, neglect, alteration, modification, tampering, or failure to follow instructions supplied with the product. This warranty does not cover normal wear and tear of o-rings or seals, and the warranty shall be void if the product is used commercially. If the product or any part of it should malfunction within the warranty period, call 1-800-977-7293. Valid only in North America. You must retain your sales receipt as proof of the date of purchase and include it with any return of the product.

H. D. HUDSON MANUFACTURING COMPANY EXCLUDES LIABLITY UNDER THIS WARRANTY FOR ANY AND ALL INCIDENTAL AND CONSEQUENTIAL LOSS OR DAMAGES.


INSIDE THE BOX (Parts may be loose in tank)

- (1) Sprayer Tank
- (1) On-off Valve
- (1) Pump in tank
- (1) Handle
- (1) Supply Tube
- Instructions
- (1) Spray Wand with nozzle
- (1) Hose with fitting and nut




HOW TO ASSEMBLE

- 1. Hose Assembly
- a.) Slide large cap nut onto hose, threads face end of hose. Insert hose barb to end of hose. Insert supply tube into hose barb.
- b.) Slide handle onto other end of hose, threads face end of hose. Insert barb end of on/off valve onto hose. IMPORTANT: Be sure hose is all the way over the barb! Tighten handle onto on/off valve.
- 2. Insert the supply tube into the tank and securely thread on the cap nut. CAUTION: Make sure the cap nut is threaded all the way down. If loose, it may come off with force or spray may escape resulting in SERIOUS INJURY.







HOW TO FILL

- A.) Pour measured amount of spray material into the open tank. Follow label directions on spray material container for amount to use.
- B.) Add water as directed. Do not fill beyond the MAX FILL line.
- C.) Insert pump and turn clockwise to seal. Do not over tighten.









HOW TO PRESSURIZE

Unlock pump handle by pushing down and turning handle. Do not unscrew pump cap or remove pump. Using the handle, pump up and down. The more you pump, the more pressure you will build up inside the tank. When it becomes difficult to pump, your tank has reached maximum pressure. Do not stand so your head is over pump.

- Use low pressure (fewer strokes) for a coarse spray.
- Use high pressure (more strokes) for a fine mist or a long-reaching stream.






HOW TO SPRAY







Push handle back to stop



Turn sprayer on its side and turn nozzle away from you. Squeeze lever or push button to "ON" and let all the air escape. Turn sprayer up-right and slowly unscrew pump from tank and remove it. Do not stand so your head is over pump.

HOW TO RELEASE PRESSURE





SERVICE AND MAINTENANCE

Visit www.hdhudson.com/FAQS

Clean and dry your sprayer after every use to greatly prolong its useful service life. Many spray materials will harden if left in the sprayer and plug up the nozzle, shut-off valve or supply tube. The soft parts, O-rings and gaskets, will ultimately wear out and need replacing, just like the oil filter on your car, for example. How often they need replacing depends on how much you spray, the spray materials you use and whether or not the sprayer is regularly cleaned after use. Call 1-800-9-SPRAYER or visit www.hdhudson.com to obtain genuine Hudson® replacement parts. If you leave your sprayer in the garage over Winter, particularly in northern areas, the soft parts may dry out and need servicing before you use your sprayer for the first time in the Spring.