

WARRANTY

WHAT IS COVERED

We warrant the product to be free from defects in material or workmanship for a period of one year from the date of original retail purchase. The word “defects” is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or customer negligence will void this warranty.

WHAT IS NOT COVERED


This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. This warranty does not cover defects due to alteration or accidents. This warranty does not cover scratches, scuffs or other cosmetic damages that may result from normal use of the product.

CARE INSTRUCTIONS


Thank you for choosing ZOOVILLAS[™] SLIDE ASIDE CRATE AND END TABLE. With a little care and maintainance, the ZOOVILLAS[™] SLIDE ASIDE CRATE AND END TABLE will provide you with comfort and enjoyment for many years to come!

- To clean panels, use clean water on a damp cloth.
- When assembling ZOOVILLAS[™] SLIDE ASIDE CRATE AND END TABLE, please handle all panels and/or hardware with care to avoid any possibilities of damages and/or injuries.
- Screw caps are optional for aesthetic purposes.


PATENT PENDING




NOTE: Please read all instructions carefully before starting assembly. Also, we recommend that the unit is fully assembled on a level surface. Two people are recommended to assemble this product. DO NOT over torque screws and bolts.




A BOTTOM PANEL 1PC




B BACK PANEL 1PC




C SIDE PANEL 1PC



D SLIDING DOOR PANEL 1PC









E TOP PANEL 1PC



F DOOR STOPPER 1PC

NOTE: Please read all instructions carefully before starting assembly.
Also, we recommend that the unit is fully assembled on a level surface.
Two people are recommended to assemble this product.
DO NOT over torque screws and bolts.

- | | | | |
|---|---|---|----------|
| 1 |  | DOWEL 6x20 | 12+2 PCS |
| 2 |  | SCREW 4x35 | 10+1 PCS |
| 3 |  | SCREW 4x45 | 2+1 PCS |
| 4 |  | BOLT 6x25 | 4+1 PCS |
| 5 |  | ALLEN KEY | 1 PC |
| 6 |  | HOLE PLUG (OPTIONAL FOR AESTHETIC PURPOSES) | 4+1 PCS |

TOOL REQUIRED



Phillips Screwdriver



** Power Tool NOT Recommended*




Only slight turn of
Cams required.


Do NOT overturn.


Reference this guide when assembling all
Cam Locks (Hardware A+B).

1




2







4



5




6




Flip-over: Right side-up

7



8



Please check contents before assembly. If any items are missing or damaged, do not take the unit back to the store. Call (775) 629-5029 or email: service@merryproducts.com for customer service and we will save you time by correcting any problems directly for you.

NOTE: Please read all instructions carefully before starting assembly. Also, we recommend that the unit is fully assembled on a level surface. Two people are recommended to assemble this product. DO NOT over torque screws and bolts.