


CARE INSTRUCTIONS


Thank you for choosing turtleplay™ CHILDREN'S TEEPEE.

With a little care and maintenance, the turtleplay™ CHILDREN'S TEEPEE will provide you with comfort and enjoyment for many years to come!

- Rinse any parts with water to clean.
- When assembling turtleplay™ CHILDREN'S TEEPEE please handle all parts and/or hardware with care to avoid any possibilities of damage and/or injury.




NOTE: Please read all instructions carefully before starting assembly. Also, we recommend that the unit is fully assembled on a level surface. Two people are recommended to assemble this product.



A

TOP POLE


X 4PCS



B

BOTTOM POLE


X 4PCS



C

CHORD

X 1PC




D

TENT


X 1PC

NOTE: Please read all instructions carefully before starting assembly.
Also, we recommend that the unit is fully assembled on a level surface.
Two people are recommended to assemble this product.



1



2



3



Please check contents before assembly. If any items are missing or damaged, do not take the unit back to the store. Call (775) 629-5029 or email: service@merryproducts.com for customer service and we will save you time by correcting any problems directly for you.

NOTE: Please read all instructions carefully before starting assembly. Also, we recommend that the unit is fully assembled on a level surface. Two people are recommended to assemble this product.