

ASSEMBLY INSTRUCTION

1.-PLACE SHADE ONTO HARP AND TIGHTEN FINIAL.

WHEN CHANGING THE BULB, TAKE OUT THE BUTTERFLY CLIP, INSTALL THE BULB, AND PUT BUTTERFLY CLIP BACK ON THE CARD

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN, NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ATTEMPT TO DEFEAT THIS SAFETY FEATURE.

