

# HEALERS URBAN WALKERS

Boot Reverse Side

XS



S



S/M



M



M/L



L



XL



Size	Paw Width (")	Length of Boot *toe to top of boot (")	AVG Circumference *from boot center point (")	AVG Weight *LB's
XS	1 1/2	3 1/2	4	10-20
S	2	4 1/4	5 1/2	30-50
S/M	2 1/2	4 3/4	6 1/4	40-80
M	3	5 1/4	7	50-90
M/L	3 1/2	6	7 1/2	65-100
L	4	7	8 1/2	95-125
XL	4 1/2	8	9 1/2	125+

## SIZING INSTRUCTIONS

Measure according to our drawings and instructions below for most accurate results. Boots do run big so if in doubt go down a size.

Note: Back paws may be smaller than front paws.

### MEASURING PAW SIZE


1. Have your dog stand on a firm surface
2. Place a blank piece of paper under a front paw and apply gently pressure to measured paw
3. Mark the paper at the top, including toenails. Add marks at the heel and both sides of the paw
4. Use a ruler to measure the width of the paw between the 2 outer pads.
5. Boot length refers to the length from the toes to wear the top of the boot will rest. Most boots lay just below the dew claw.
6. Measure the circumference – This is the thickness of the paw. Since this is a wrap-around boot the measurement provides an indication on the average thickness of a paw that the boot will fit.
7. Use the chart to choose the dog shoe size that is the closest fit for the entire paw including toenails and fur. If it's borderline, go for the larger size.

## URBAN WALKER MEASUREMENTS

Paw Width



Paw Length



Paw Circumference



Need Help with Sizing Call  
Manufacture at  
800 924 7036