
## Dispensing Rate Chart for Electric Hand Seeder Instructions

To adjust for various seed or granule sizes, slide lever located underneath orange trigger button to adjust flow.





## Minimum Opening: is meant for the tiniest granules measuring around

1/32 inch

## **Max Opening:**

is the most open and free flowing setting on the lever. It is meant for larger granules measuring around 1/8 inch

This system is designed to go off feel and sight rather than a chart.

## **Common Seed Opening Sizes**

1/32 inch 1/16 inch 1/8 inch Millet Alfafa Wheat Rape Seed Oats **Beets** Bermuda (common) **Sudan Grass Barley** Bermuda (giant) **Buck Wheat** Soybeans Clover Rye Grass Flax **Turnip** Fescue Sorghum Sudan Rye