

THRU-CORE INSTRUCTIONS



1 Position valve at 6 o'clock on tire.




2 Shake vigorously for 15 seconds.



3 Turn can upside down and screw plastic nozzle clockwise onto tire valve.



4 Allow 30 seconds for can to discharge fully. Unscrew nozzle when empty.



5 Inflate tire to recommended pressure.



6 Drive. Stop. Verify seal and check pressure.