


operating instructions
Part Number: 1591460

## 30 IN Direct Drive Drum Fan

**WARNING:** To reduce the risk of fire or electrical shock Do Not Use This Fan With Any Solid State Speed Control Device.



## READ AND SAVE THESE INSTRUCTIONS

**Specifications:** 110-120 Volt A/C polarized grounded plug with 7.5ft supply cord. Do not remove grounding conductor from lug or use with an extension cord.

**Warning:** To reduce the risk of fire or electric shock, do not use with any solid state speed control device.

This fan motor is equipped with an automatic reset overload device. The fan may start unexpectedly. Do not put any objects through grilles into blade or motor.

This fan is designed for indoor use only. Do not expose to the elements or allow to become wet.

Do not use to exhaust hazardous chemicals or vapors. Unplug unit for storage, when not in use or moving locations.

**Maintenance or Service Instructions:** Always unplug or disconnect the fan from the power supply before servicing Remove grilles to clean with mild detergent, allow to dry, and reinstall.

## PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

If you have any questions or need assistance with assembly or parts,

Please call us toll-free at: 888-376-9601 Mon. - Sat. 7am to 9pm CST and Sun. 8am - 7pm CST.