







Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>
 If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

3-TIER PLANT STAND WITH DECORATIVE SCROLL DESIGN HMI-757

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



 Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
 Save the packing slip.

No.	PARTS	QTY.
A	 Frame	1
B	 Bottom Shelf	1
C	 Middle Shelf	1
D	 Top Shelf	1

25 pounds
 11 kg
 Weight Capacity
 per Shelf



**SCAN THIS CODE
 WITH YOUR
 SMARTPHONE
 TO VIEW OUR
 ASSEMBLY VIDEO**



Shelves install into the frame very snugly. Assistance may be required to align shelves into the frame during assembly.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

ASSEMBLY

STEP 1

A: 1



Unfold Frame (A).

STEP 2

B: 1



Install Bottom Shelf (B) onto the bottom of Frame (A).

STEP 3

C: 1



Install Middle Shelf (C) onto the middle of Frame (A).

STEP 4

D: 1



Install Top Shelf (D) onto the top of Frame (A).

Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface.

CLEANING: Wipe with a soft, dry or slightly damp cloth. Do not use harsh chemicals, abrasive materials or a pressure washer to clean the unit.

SCRATCHES: The powder coating on the item is tough and durable; however, even with normal use, some scratching is inevitable. Scratches can be repaired with a rust-resistant paint (not included). **WARNING:** The one-year warranty does not cover damages or defects caused by painting and/or repairs.

WINTER CARE & STORAGE: Store in a dry, indoor location. Covering while in storage will help prevent dust buildup.

! SAFETY STATEMENTS & WARNINGS !

- Do not overload or exceed the weight capacity of the shelves.
- Ensure weight is evenly distributed on each shelf to prevent sagging.
- Do not move the stand while in use.
- Do not sit, stand, or climb on the unit.
- Do not use harsh chemicals or abrasive materials to clean the unit.
- Store indoors during the winter and severe weather conditions.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.