

|--|

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <a href="https://tiny.cc/SunnydazeWarranty">https://tiny.cc/SunnydazeWarranty</a>


If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: <a href="mailto:customerservice@sunnydazedecor.com">customerservice@sunnydazedecor.com</a>, or via our contact us page at <a href="https://tiny.cc/SunnydazeContact">https://tiny.cc/SunnydazeContact</a>

# DELUXE STEEL U-SHAPE HANGING CHAIR STAND


**TF-554** 

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid scratching/damaging the finish.



### **ASSEMBLY**



### (!) ASSEMBLY TIP

Ensure parts align correctly before fully tightening hardware.

#### STEP 1

Align Left Base Pole (4) and Right Base Pole (5), as shown.


Fasten the base poles using 2x Short Bolt Set (F) and 4x Washer (S).



Carefully snap Foot (G) onto the base, ensuring they are evenly spaced.


Place 1x Bottom Pole (2) onto the assembled base, ensuring the holes of the pole align with the base.

Use 4x Short Bolt Set (F) and 8x Washer (S) to secure the pole to the base. Secure the second bottom pole the same way.



STEP 3

Slide 2x Top Pole (1) onto the bottom poles, ensuring the holes of the top pole align with the bottom pole. Use 1x Long Bolt Set (E) to fasten each top pole to the bottom pole.



STEP 4

Secure Support Bar (3) between the top poles using 2x Bolt (U).

Place Pin (D) into the top support pole. Insert Extension Spring (C) through the bottom of Pin (D).

### **USE & CARE**

Under normal use, Sunnydaze hammock chair stands will last for years. It is important to follow basic use & care tips to prolong the life of your stand.

- **SAFE USE:** Do not use this chair stand for swinging, bouncing, jumping, twisting, or other excessive movements; doing so may cause serious injury, including, but not limited to, the stand tipping over.
- **CHILDREN:** Supervise children at all times. Do not allow children to play on or sleep in any hanging chair. Chair not included.
- **INSPECTION:** Ensure the stand is assembled correctly and all hardware is securely tightened before each use.
- **CLEANING:** Use a soft cloth, warm water and soap to wipe down the stand if necessary. Dry the stand after cleaning to prevent rust.
- **SCRATCHES:** The powder coating on the stand is tough and durable but, even under normal use, some scratching is inevitable. To avoid excessive rust, wipe these areas as needed to remove moisture.
- **STORAGE:** Store the stand indoors when not in use. Cool, dry locations are recommended to prevent damage and rust that may result from exposure to moisture.

### **TROUBLESHOOTING**

- If the stand feels unstable, make sure it is on a level surface and the feet are correctly and evenly distributed.
- If the stand is making noise when in use, check to make sure all hardware is fully tightened.



### **△WARNING**:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.



Purchase Date: / / / Order/Customer Reference Number:


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <a href="https://tiny.cc/SunnydazeWarranty">https://tiny.cc/SunnydazeWarranty</a>
If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email:


customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

# LIZA EGG CHAIR

Read all assembly and care instructions carefully before using this product.

Save this manual for future reference.






## **▲** CAUTION **▲**


This egg chair is not designed for use as a swing. Bouncing, swinging, or any other significant movements while in the chair may cause serious injury.

Inspect the chair and hanging hardware for damage before each use.

The safety strap must be used with or without the Sunnydaze Egg Chair Stand.

Weight Limit: 550 lbs.





Step 1

Unfold the chair so the seat is flat.

#### Step 2

Place the seat cushion into the chair. Tie the cushion and pillow to the chair ropes. Do not tie to the metal frame.

#### **USE & CARE**

With proper care and under normal use, Sunnydaze egg chairs will last for years. It is important to follow basic use & care tips to prolong the life of your egg chair.

- HANGING: Hardware to hang this chair on a Sunnydaze Egg Chair Stand is included. If this chair is used without the Sunnydaze Egg Chair Stand, consult a professional for installation and anchoring hardware requirements.
- · SAFE USE: Do not swing, bounce, jump, twist, or other make other excessive movements while using this chair; doing so may cause serious injury. Do not use this chair without the safety strap; this strap helps keep the chair safely in place while getting in and out of the chair.
- CHILDREN: Supervise children at all times. Do not allow children to play on or sleep in hanging chairs.
- INSPECTION: Check the seat, ropes, and frame for damage before each use.
- . CLEANING: Wipe with a damp cloth. For tougher stains, use mild detergent and a soft cloth to gently scrub. Rinse thoroughly and lay flat to air-dry to prevent mold and mildew growth.
- STORAGE: Store indoors during winter and inclement weather. Cool, dry locations are best to help prevent damage. Exposure to moisture may cause mold and mildew growth. Prolonged exposure to sunlight will cause the cushions to fade.

### SAFETY STATEMENTS & WARNINGS 1




- · Do not exceed the weight limit: 550 pounds
- · Sunnydaze Egg Chair is not a swing. Do not swing, bounce, jump, twist, or spin in the chair.
- For safety, the chair must be used with the safety strap provided.
- Do not loop the safety strap around the ropes or rattan material of the chair.
- · Inspect the chair for damage and ensure all materials are intact before each use.
- Do not allow children to use this product without adult supervision.

#### Safety Strap Installation:

Only loop the strap around the frame of the chair, as shown.

Strap shown installed on a Deluxe Sunnydaze U-Shape Chair Stand (not included).



Any modification to the product or failure to follow recommended care will void the product warranty.

### **!**WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.