



Purchase Date: / / Order/Customer Reference #:	
--	--

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at https://tiny.cc/SunnydazeWarranty If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

OUTDOOR TORCH STAKES

Read all information carefully before using this product. Save this manual for future reference.

These torch stakes make it easy to secure your favorite Sunnydaze Decorbrand torches into the ground. Each stake fits poles up to 1-1/4" diameter.

INSTALLATION

- Choose a location with soil that is firm enough to support the stake while it is in use, and where stake spike can be fully inserted into the ground. DO NOT INSERT STAKE INTO LOOSE SOIL.
- 2. Fully insert the spike of the torch stake into the ground. Ensure that the stake is straight and upright to prevent leaning.
- 3. Place the torch (not included) through the stake and into the ground approximately 2".
- 4. Tighten the thumbscrew to secure the torch. Torch not included.
- On not use stakes with torch poles smaller than 3/4" diameter.

Any modification to the product or failure to follow recommended care will void the product warranty.

≜WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Sunnydaze Decor •••• SunnydazeDecor.com