

# **WARRANTY**

### WHAT IS COVERED

We warrant the product to be free from defects in material or workmanship for a period of one year from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or customer negligence will void this warranty.


#### WHAT IS NOT COVERED

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. This warranty does not cover defects due to alteration or accidents. This warranty does not cover scratches, scuffs or other cosmetic damages that may result from normal use of the product.

# **CARE INSTRUCTIONS**


Thank you for choosing ZOOVILLAS'™ FAIRVIEW TRIPLE DOOR CRATE. With a little care and maintainance, the ZOOVILLAS'™ FAIRVIEW TRIPLE DOOR CRATE will provide you with comfort and enjoyment for many years to come!

- To clean panels, use clean water on a damp cloth. THIS PRODUCT IS FOR INDOOR USE ONLY.
- When assembling ZOOVILLAS'™ FAIRVIEW TRIPLE DOOR CRATE, please handle all panels and/or hardware with care to avoid any possibilities of damages and/or injuries.
- Screw caps are optional for aesthetic purposes.




NOTE: Please read all instructions carefully before starting assembly. Also, we recommend that the unit is fully assembled on a level surface. Two people are recommended to assemble this product. DO NOT over torque screws and bolts.

ZOOVIIII PTH1072020100 / PTH1082021700 - FAIRVIEW TRIPLE DOOR CRATE, LARGE



NOTE: Please read all instructions carefully before starting a Also, we recommend that the unit is fully assembled on a level Two people are recommended to assemble this product. DO NOT over torque screws and bolts.





9 FRONT / REAR TRIM

X 2PCS

10 MAGNET SUPPORT

X 1PC

Α —		DOWEL —	18+1 PCS
В —		LOCKING BOLT —	24+2PCS
c —		CAM —	24+2 PCS
D —		SCREW CAP (OPTIONAL)	24+2 PCS
E —		DOOR LOCK —	· 2 SETS
F —		DOOR LOCK SCREW 3X14MM	8+1PCS
G —		DOOR BOLT —	1sets
н —	<b></b>	DOOR BOLT SCREW 3X12MM	4+1PCS
ı —		DOWEL 6X15MM	8+1PCS
J		SELF TAPPING SCREW 4X20MM ———	13+1PCS







Reference this guide when assembling all Cam Locks (Hardware B+C).


NOTE: Please read all instructions carefully before starting a Also, we recommend that the unit is fully assembled on a level Two people are recommended to assemble this product. DO NOT over torque screws and bolts.




























9







TOP



10











13




Open the front and side doors





### The door can be assembled on either side





Please check contents before assembly. If any items are missing or damaged, do not take the unit back to the store. Call (775) 629-5029 or email: service@merryproducts.com for customer service and we will save you time by correcting any problems directly for you.

NOTE: Please read all instructions carefully before starting assembly.

Also, we recommend that the unit is fully assembled on a level surface.

Two people are recommended to assemble this product.

DO NOT over torque screws and bolts.