Warning: Polywire, polytape, and polyrope are not to be used as the sole form of animal containment and must be used in conjunction with a permanent perimeter fence. Do not use with continuous current energizers.

Setup: Clear fence line of vegetation that may cause shorts. Connect the energizer to the conductive line using the proper connector. Do not allow the electric fence to be loaded with snow or debris. Check the electric fence components on a regular basis to ensure the system is working properly.

