

Dual-Ride Glider

Glider


Glider

NE 3452
WS 3452




WARNING: Assembly by adult.
AVERTISSEMENT: L'assemblage doit être exécuté par un adulte.
ADVERTENCIA: El ensamblaje lo debe hacer un adulto.


**FOR PRIVATE BACKYARD USE ONLY
DO NOT USE IN PUBLIC SETTINGS!**
**SOLAMENTE PARA USO EN EL PATIO TRASERO PRIVADO
¡NO DEBE USARSE EN LUGARES PÚBLICOS!**
**PRODUIT NON-CONÇU POUR UNE UTILISATION COMMERCIALE
UTILISEZ UNIQUEMENT EN RÉSIDENCES PRIVÉES!**




Tools required:
Outils requis:
Herramientas requeridas:




WRENCH
CLÉ
LLAVE



TAPE MEASURE
RUBAN À MESURER
CINTAMÉTRICA




SOCKET & WRENCH
DOUILLE ET CLÉ DE
CUBO DE DE LLAVE DE
TRINQUETE



SCREWDRIVER
TOURNEVIS
DESTORNILLADOR



Glider End
x2



Glider Chain x4




Glider Seat x1




Quick Link
x6




Lock Nut
x6



Flat Washer x12



Eye Bolt x4




Hex Bolt x2


Specifications subject to change without notice. Les spécifications peuvent changer sans la notification. Las especificaciones sujetas cambiar sin nota.
Manufactured for / fabriqué pour / fabricado para: Backyard Play Systems • 1000 Ternes Drive, Monroe, MI 48162 • USA • 1-866-890-2211 • customerservice@backyard-play.com
Made in China / Fait en China / Hecho en China • Printed in China / Imprimé en China / Impreso en China

IMPORTANT! Even though some hardware may be inserted by manufacturer, tighten all Lock-Nuts as indicated to verify they are fully engaged.


Eye bolts should be oriented perpendicular with Glider seat.




It is helpful to use a screwdriver to hold eye bolt in place when tightening lock nut.



Tighten Lock Nut until three (3) threads are exposed.





GLIDER

FINAL INSPECTION

