

IMPORTANT SAFETY INSTRUCTIONS AND ASSEMBLY INSTRUCTIONS

Table Lamp ITEM:AER568

Careful unpack all lamp parts from the carton.

1. Carefully remove all parts from the carton and place them on the flat soft surface.
2. Insert harp (C) onto saddle (B).
3. Place shade (D) onto harp (C) and tighten finial (E).

BASIC PRECAUTIONS

- Unpack and place all parts on a smooth, flat surface.
- Do not attempt to replace bulb while the lamp is plugged into an electrical outlet.
- Do not use outdoors or near water.
- Clean with a soft, dry cloth.
- Remove plastic cover from the shade before use.

POLARIZED PLUG

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

*** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

