

ASSEMBLY INSTRUCTIONS

FOR ITEM NO. ABS1338/ABS1338SNG/ABS1338WH/ABS1338OAT
PLEASE ASSEMBLE THE PRODUCT
BY FOLLOWING STEPS:

1. Unpack all parts from cartons carefully.
2. Fasten the socket w/neck (B) onto lamp body (A) until tight;
3. Place the harp (C) onto the saddle around socket (B);
4. Place the shade (D) onto the harp (C);
5. Fasten the finial (E) onto the harp (C) until tight.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

