




## Dining Bench CF5023




## PART LIST




## HARDWARE LIST







Step 1 . Attach pedestal support (part D) to legs (part B) using flat washers (part #3) , spring washers (part #2), hex nuts (part #1) and wrench (part #4).



Step 2 . Attach bench supports (part E) to legs (part B) using flat washers (part #3), spring washers (part #2), hex nuts (part #1) and wrench (part #4).



Step 3. Lay assembled unit (parts B, D & E) upside down on soft surface, such as carpet. Attach leg support (part C) to legs (part B) using small flat washers (part #7), small spring washers (part #6), bolts (part #5) and allen wrench (part #8).



Step 4. Lay seat panel (part A) upside down on soft surface, such as carpet. Attach assembled unit (parts B, D & E) to seat panel (part A) using small flat washers (part #7), small spring washers (part #6), bolts (part #5) and allen wrench (part #8).

