

# Vacuum Kit

---



**Item# LC901**

**Specification: 4"x10' extension hose with vacuum nozzle**


Type of waste permitted: Light, loose, dry waste such as leaves, grass clippings, or sawdust.

**NOTES:** The vacuum is engineered for small, loose waste and for cleaning around decorative landscaping and flower beds. Twigs, wet leaves, and other bulky materials will clog the hose or obstruct the shredding chamber.

## TROUBLE SHOOTING:

PROBLEM	POSSIBLE CAUSE	SOLUTIONS
Vacuum not working	1. Hopper gate not closed.	1. Slide gate to closed position.
	2. Cone cover not installed.	2. Install the cone cover.
	3. Hose not attached properly.	3. Clear blockage or replace.
	4. Engine not running at full RPM.	4. Set throttle control to FAST if equipped.

## PART LIST



Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	Adapter	1	6	Handle grip	1
2	Hose adapter	1	7	Vacuum nozzle	1
3	Extension vacuum hose	1	8	Plastic ring	1
4	End cap	1	9	Hex bolt	1
5	Handle	1	10	Locknut	1