ASSEMBLY INSTRUCTIONS FOR ITEM NO.ABS1661 PLEASE ASSEMBLE THE PRODUCT BY FOLLOWING STEPS:

- 1. Unpack all parts from cartons carefully.
- 2. Place the harp (B) onto the socket assembly(A);
- 3. Place the shade (C) onto the harp(B);
- 4. Fasten the finial (D) onto the harp(B) until tight.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

