


6 Ft Picnic Table Assembly

Parts Include:

- A- Table Top Rails (2)
- B- Bench Rails (4)
- C-Legs Lower Base (2)
- D- Upper Table Legs (2) E- Leg "Y" Hinges (2)
- F- Hinge Anchor Rod (2) G-Bench Support Rod (2)

- 182.7L*23.5W*48H cm Resin Benches (2)



Step 1:

Remove the benches from the assembled package and unpack all the parts.


Completely read the assembly instructions before starting.



Step 2:

Place one of the Table Top Rails in position under the Table Top.






Step 4:


Insert one end of the Hinge Anchor Rods into the positioned Table Top Rail.

(Note the position of the Leg "Y" Hinges.)



Step 5:

Insert one end of the Upper Table Legs Rod into the large hole in the positioned Table Top Rail. (Note: the shape of the base of the Upper Table Legs should match the indentations in the underside of the Table Top.)



Step 6:

Insert the open ends of all four (4) the rods into the other Table Top Rail then place the rail in position under the Table Top. Step 7: Using 12 (5*30mm) Self-Tapping Screws secure the Table Top Rails in place.

Step 8:

Table Top Rail

Attach the open ends of the Leg "Y" Hinges to the bolts welded into the Upper Table Legs and securing with the four (4) 9.9*10.73mm Screw Caps. Welded Bol