



Purchase Date: \_\_\_ / \_\_\_ / \_\_\_ Order/Customer Reference Number: \_\_\_\_\_

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty> If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: [customerservice@sunnydazedecor.com](mailto:customerservice@sunnydazedecor.com), or via our contact us page at <https://tiny.cc/SunnydazeContact>

# GENERAL CARE GUIDE FOR HANGING CHAIR HAMMOCKS

Save this guide for future reference.

## USE & CARE

- **SAFE USE:** Take your time getting in and out of the hammock. Any hammock may tip if your weight is not centered.
- **SUN EXPOSURE:** All fabrics will eventually fade and degrade from sun exposure. The less direct sunlight the hammock is exposed to, the longer the life of fabric and ropes will be.
- **CHILDREN:** Supervise children at all times while using this product. Do not allow children or pets to play in the chair hammock. Excessive swinging or rough play will damage the hammock and may cause injury.
- **INSPECT:** Before each use, inspect the ropes, fabric and spreader bar for wear or weakness.
- **CLEANING:** Clean when soiling or staining is present, and before storage.
- **STORAGE:** Store indoors, in a dry location during inclement weather, winter, and when it will not be used for an extended time. Ensure it is completely dry before storing to prevent mold and mildew growth.

## CLEANING



HAND-WASH ONLY



DO NOT USE BLEACH OR FABRIC SOFTENERS



LAY FLAT TO DRY



DO NOT IRON

Spot clean with a damp cloth.

For more stubborn stains, hand-wash in a bathtub or kiddie pool using mild soap and a soft-bristled scrub brush. Soaking may be required for heavily soiled fabric, pillow or ropes. Keep the wooden spreader bar out of the water as much as possible.

Thoroughly rinse all soap residue. Air-dry on a flat surface to prevent the ropes from stretching. The ropes may shrink slightly while drying, but will stretch back out with use.

## SAFETY STATEMENTS & WARNINGS

- Before each use, inspect your hammock for wear or weakness. Do not use if the ropes are frayed or fabric is torn.
- Excessive swinging and other rough play may result in serious injuries.
- Small children should not use the hammock unsupervised.
- Pets should not be allowed into hammocks as it may result in injuries or damage the product.
- Do not exceed the recommended weight capacity of the hammock.
- Never untie the ropes of the hammock.

Any modification or failure to follow the recommended care will void the product warranty.

## WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.