

Prior to first use, the tub must be thoroughly rinsed. All the packaging must be removed, including chimney protective film.

It is strictly forbidden to heat empty hot tub.

-It is important to remember that you cannot preheat wood heater too early before the water is allowed into the hot tub, as heat will damage the hot tub. It is recommended to start the wood heater with about 10 cm of water left to the top of the tub.

-The water can only be drained from the tub when the shoulders are completely cooled. If you hurry to drain the water, the wood heater's heat will damage both the tub and wood heater.

-The hot tub must be thoroughly washed every time before using it (fiberglass surfaces must be cleaned using the same chemicals used to clean the pools, avoiding chlorine as it will damage the fiberglass surfaces and the nozzles).

-It is recommended to clean the wood heater every 3-5 kindles, using small spatula.

-It is recommended to impregnate the wooden finish of the tub - paint (impregnant, oil for wood, paint for wood) at least once a year.



IMPORTANT – WHEN USING A HOT TUB WITH ELECTRICAL SYSTEMS, ELECTRICAL DRAINAGE RELAY MUST BE INSTALLED IN THE ELECTRICAL INSTALLATION SYSTEM.

NEVER LEAVE THE HOT TUB UNATTENDED WHILE THE WOOD HEATER IS ON OR STILL HOT.

CHILDREN CANNOT BE LEFT IN THE HOT TUB WITHOUT ADULT SUPERVISION.

-It is strictly forbidden to use chlorine and salts.

-Do not add too much firewood (more than two thirds of the height of the heater) to the heater, do not use wet or chemically treated firewood.

-It is strictly forbidden to heat the wood heater of the hot tub until the water has reached the required limit - i.e., 10cm to the top of the tub.

-It is strictly forbidden to drain water from the plastic tub while wood heater is hot.

-It is strictly forbidden to store water in a plastic tub when the outside temperature is minus.

- The temperature must be checked regularly to avoid burns.

-In minus temperatures, always drain the water from the tub to avoid freezing and breaking the tub.

The plastic tub should be placed on a flat, solid surface:

-The purchased tub has to be placed on a flat, leveled and solid surface (e.g., wooden outdoor terrace, concrete surface). If the product is placed incorrectly or on an uneven surface, the tub may lose its strength, stability or even its aesthetic appearance.

-It is recommended to build the hot tub no closer than 2-4 meters from the buildings. Safety requirements must be met depending on the situation.



-When building the tub on a wooden base, it is necessary to place a metal plate under the bottom of the heater.

Hydromassage system and air bubble system:



-Do not start any systems without filling the tub with the required amount of water. When draining the water from the tub, all systems must be switched off.



-In the cold season, after filling the tub with water, the massage system can be activated only when the water heats up to +30 degrees.



-After releasing the water from the hot tub, keep the system, active for 30 seconds to remove water from the system.

Using the hot tub:

-It is recommended to go into the tub when the temperature is not higher than 38 degrees in winter and 36 degrees in summer.

-It is strictly forbidden to jump into the tub from the edges of the tub.

-Be careful with the heater and chimney to avoid burns.

-When the water temperature rises above 40 degrees, cooling can be done by adding cold water or simply putting snow.

- It is mandatory to take a shower before entering the hot tub so that the water will remain cleaner for longer. The bathtub and its water should be cleaned after bathing.

The manufacturer accepts no liability for damage or other consequences caused by improper use of the hot tub or by using the hot tub in a manner other than described in the manual.

**All units of temperature and measure are based on the metric system