

# Cuisinart®

## 3 Piece Magnetic Grilling Set CSS-33

### INSTRUCTIONS

#### FILLING YOUR SPICES

To fill the shaker and rub container hold the base firmly and twist counter-clockwise from the black band at the top. That will give you access to the spice chamber. For the grinder you'll need to flip the container upside down and pull firmly on the stainless steel base to access the chamber. This is pressure fit so no need to twist. Make sure to press firmly back into place when filled.

#### USING YOUR SET

For the shaker and rub simply spin the stainless steel top to reveal the opening and shake out desired spices. Spin the cap back to protect from the elements. The grinder features a pressure fit cap. Pull on the stainless steel cap (marked G) to open. Turn the grinder upside down and twist the bottom stainless steel portion to grind. Replace the cap to protect from the elements.

Each piece is fitted with a rare earth magnet in the base so you can attach your spices to various metal surfaces for easy access.

#### CLEANING

Clean the surfaces with a moist cloth. Do not submerge. Do not place in dishwasher. Prevent water from getting into the chamber. Store in a dry place.



#### GRINDER

Great for pepper and other hard ground spices

#### RUB

Wide mouth container perfect for BBQ Rubs

#### SHAKER

Smaller shaker openings great for salts

