



UNPACKING INSTRUCTIONS

Unpacking the DR POWER GRADER

Tools and Supplies Needed:

- Gloves
- Wire Cutters
- Safety Glasses

CAUTION

- The Box Straps, Staples and Cable Ties can snap towards you when you cut them. Wear Safety Glasses and Gloves when cutting the Straps, pulling the box open and cutting Cable Ties to protect your eyes and hands from injury.
- You will need two people to lift the Power Grader Frame from the box. The Frame is heavy and you could be injured if you don't have help.

1. Cut the Strapping from around the Box with Wire cutters.
2. Pull the Box Flaps open.
3. Cut the Cable Ties with Wire Cutters and remove the Axle Assembly, Tow Bar and Crank Post (**Figure 1**).
4. Remove the Cardboard Insert.
5. Cut the Cable Ties using the Wire Cutters and remove the Parts Box, Control Box Assembly and Wheels (**Figure 2**).
6. With the help of another person, grab the inner box at the hand holds and lift the Grader Box Assembly from the shipping Box.

Continue with the "Assembling the DR POWER GRADER" section in Chapter 2 of your DR® POWER GRADER Safety and Operating Instructions manual to continue with the assembly of the Grader.

If there are any questions contact us at www.DRpower.com or call 1-800-DR-OWNER (376-9637). Do not discard the shipping materials until you are fully satisfied with your new DR® POWER GRADER.




Figure 1




Figure 2