





67" FLIP FLOP BOOKCASES FF6730 | FFC6712 | FFSQ6712


BEFORE YOU ASSEMBLE:

- Place all parts on a clean, smooth surface to avoid scratching the parts
- Check to be sure you have all parts and hardware
- Remove all wrapping materials, including any staples & packing straps
- Keep all hardware, small parts and packaging out of reach of children

STEP 1:

Unfold your bookcases and flip down shelves.


Next, attach the top of one of the bookcases by lining it up with it's respective dowels and pressing into place. Finally, attach the two sections together by lining up the dowels and stacking one piece on top of the other.



OPTIONAL: Wall Anchor Instructions

Organize your parts and hardware. You will need (1) person and a Phillips head screwdriver.

Hardware:



STEP 2a: Attach the Strap(**C**) to the highest cross brace that spans the back of your bookcase with 2 Small Screws(**A**).

STEP 2b: Attach the Strap(**C**) to the wall behind the bookcase by using the Large Screw(**B**).

Note: Depending on the construction of your wall the Large Screw(**B**) should be screwed into a wall stud. If there is not wall stud available then (**B**) should be screwed to the wall using an appropriate wall screw (not included).

