

**3**
MODES**LED**
TECHNOLOGY

RECHARGEABLE

MAGNETIC

IPX4
WATERPROOF**POWER/MODE BUTTON**

- Press to turn ON
- Press to change brightness mode:
 1. High
 2. Medium
 3. Low
 4. Off
- After 5 seconds of no mode change, next button press is OFF

CHANGE BRIGHTNESS

- Press power button within 5 seconds of turning light on to change brightness

CHANGE LIGHT COLOR TEMPERATURE

- Press light color button to change color temperature:
 - Cool White 5400K
 - Warm White 4000K

CONTROL PANEL

Power/Mode



← Light Color

← Battery Level Indicator

BATTERY LEVEL INDICATOR

Battery level indicator LEDs turn on when light is on.

- (4) 100-75%
- (3) 74-50%
- (2) 49-25%
- (1) 24-0%

CHARGING

1) Remove charge port cover 2) Plug in charger
*included charger output of 8.4V 1.5A. If using a charger other than included ensure similar voltage and amp specifications, not doing so can result in a damaged battery.

- - Battery Level Indicator lights blink while charging then solid glow when fully charged.

***Please recharge a stored unit every four months to maintain optimum performance of the lithium-ion batteries and maximize charging levels. Battery excluded from warranty.*

LED SAFETY WARNING

This product contains high intensity LED devices. To prevent permanent eye damage, do not stare into the light beam at close range.

SPECIFICATIONS

Model # 12680

LIGHT

2000 Total Max True-Lumens

Flood Light: 667 Lumens per head

Cool White 5400K or Warm White 4000K

RUNTIME

High: 1.5 hours

Low: 3 hours

BATTERY

2x 18650 Rechargeable Lithium-ion

Voltage: 7.4V

Capacity: 2000mAh

OTHER

Tripod Mount M20x1.5 thread [tripod not included]

IPX4 Waterproof Rating

Weight: 1lb 13oz (0.82Kg) [battery incl.]

PACKAGE CONTENTS

[1] TRI-MOBILE Light

[1] DC Charger

1 Year warranty

