



Proudly Designed in Colorado



Have questions?

Call or email one of our Colorado based customer service representatives. We want to help!

customerservice@gobiheat.com

(801) 228 - 1948



QUICK START GUIDE

For Jackets, Vests, and Hoodies

GET STARTED

HARNESS THE HEAT OF THE DESERT

1

Locate the battery pocket
found inside of the jacket on
the front-left side



2

Attach the battery to the cable
found inside the pocket, place
the battery inside the pocket,
then zip the pocket closed.



3

Wake Battery

After 24 hours of inactivity, press button to wake up battery. Press any time to check battery life.



Turn On Jacket

Hold button found on garment for up to 5 seconds. Once light comes on, press button again to cycle through heat settings.



WASHING INSTRUCTIONS

1. Remove battery from heated clothing.
2. Replace the protective cap on your cable.
3. Place cable back in pocket, ensure cable is not pinched.
4. Zip the battery pocket closed.
5. Wash on gentle washing and drying cycles, or lay flat to dry.

BATTERY CARE

- Fully charge and discharge the battery every 3 - 6 months
- Only use Gobi Heat batteries, chargers, and cables with your product.
- Discontinue use if your battery becomes damaged, dropped, tampered with or otherwise compromised.
- When traveling with your battery, pack battery into carry-on luggage not checked luggage.
- Do not dispose of battery in trash. Please use proper recycling.

EXPAND YOUR HEAT

Find other heated products at gobiheat.com/shop



SUMMIT AND CREST
Heated Beanies



STEALTH
Heated Glove Liners



TREAD
Heated Socks



EXTRA BATTERY
Double your heat time



ZEN
Portable Heated Blanket



TERRAIN
Heated Camp Chair

Use Coupon Code **MOREWARM** to Get 10% Off

SAFETY INFORMATION

CAUTION! If you feel uncomfortable tingling heat or if the skin turns red, there is a risk of burns. Turn off the device immediately and stop use immediately. Read the safety information carefully before first use.

- Never use if inner lining is wet.
- Heating elements should not be allowed to touch bare skin.
- Shut off power immediately if discomfort occurs.
- Do not allow the wires in the product to be pinched.
- Discontinue use of this product if it stops working correctly or heats inconsistently.
- Do not use pins on or around this jacket as they can cause damage to wiring.
- Remove the battery pack from the battery pocket before washing. Be sure to secure the connector into the battery pocket before washing.
- Do not dry clean. Do not use dry-cleaning fluid on this item. Do not bleach. Cleaning solvents may have a detrimental effect on the insulation of the heating elements.
- Do not iron.
- Do not remove sewn in labels. These carry important information.
- The device may interfere with other electronic devices such as pacemakers and more. Consult with your doctor before use.
- Do not use if you have impaired temperature sensitivity. Consult with your doctor before use.
- Keep the product out of the reach of children, as it contains small parts which could be easily swallowed.
- Always turn off the device and disconnect the batteries when it is not in use.
- Only use Gobi Heat provided batteries, chargers, and cables.
- This item should be serviced by a qualified repair person using only identical replacement parts.

YOU SHOULD BE EARNING REWARDS

EARN POINTS TOWARD AWESOME REWARDS

1



Go to
[GOBIHEAT.COM/REWARDS](https://gobiheat.com/rewards)

2



Create an account using
the email you used to
purchase your product.

3



Earn rewards for this
purchase along with all future
purchases, leaving a review,
and referring friends.

YOUR 1 YEAR WARRANTY

Gobi Heat stands behind its products. Each of our products is warranted to be free from defect of material and workmanship for one (1) year. This year is calculated from the date the product ships from Gobi Heat. Our batteries are warranted for ninety (90 days).

REGISTER PRODUCT / SUBMIT CLAIM

Go to gobiheat.com/Warranty to register or submit a claim. If you are experiencing issues with your product, please reach out to customer service at customerservice@gobiheat.com first.

This warranty is offered only to the original purchaser and is non-transferable. The purchaser is responsible for the cost of returning the product to Gobi Heat. After our examination determines the product is indeed defective, we will repair or replace said product and reimburse shipping costs (up to \$15 USD). This warranty does not extend to damage resulting from repairs attempted by anyone other than Gobi Heat. Furthermore, the warranty does not apply if it is determined that the product has been altered, abused or used in a manner for which it is not intended.