

## **Instruction Manual**

Please save this manual for future reference.

Thank you for purchasing this Luxen Home product. This product has been manufactured with the highest standards of safety and quality.

## **Use and Care Instructions for your Planter**

We recommend cleaning the planter before using it. New planters may often have residue from production.

Any time you are putting new soil into a planter, it is best to clean the planter first.

## Items you need:

Fiberclay, MgO, or Resin – water, mild soap, or bleach (optional) and a soft brush

## What you need to do:

- 1. Empty your planter of any dirt and dead plant material
- 2. Rinse the planter with a hose to remove dirt sticking to the sides
- **3.** Clean and Scrub!

When cleaning the planter, use a mixture of water and mild household dish soap. Use a soft brush to clean the insides. Let the planter dry before planting anything in it.

By cleaning your planter regularly, you will not only extend the life of the planter, but also allow for healthy plants to grow. You will enjoy the results for many seasons to come.

Contact: sales@winsomehouse.com