


<b>Product Name:</b>	Set of 3 Bird Solar Light Garden Stakes
<b>SKU #:</b>	WH154

Thank you for purchasing this Winsome House product. This product has been manufactured with the highest standards of safety and quality.



### Instructions:

- Assemble the solar garden stake light as shown above.
- Push the on/off button to the on position.
- For best results, allow to charge in direct sunlight for a minimum of 8 hours.
- After fully charged, product will automatically light at night.
- To extend battery life, turn to the off position when not in use.
- Battery: rechargeable AA Ni-MH 300mAh 1.2V 1pc (included)

### Trouble Shooting Tips:

Light will not switch on when	<ul style="list-style-type: none"> <li>• Ensure that the power switch on the Part A is in the ON position.</li> <li>• Ensure that the battery has been fully charged in direct sunlight for one sunny day.</li> <li>• Check to see that the solar panel is not near the night time light sources, such as street lights.</li> </ul>
Light switches on during the day	<ul style="list-style-type: none"> <li>• Ensure the light is not placed in shady area.</li> <li>• Ensure the solar panel is facing towards direct sunlight.</li> </ul>
Light quickly flashes on and off	Battery charge may be low. Turn the power switch to the ON position and charge the battery for two (2) sunny days, ensuring the solar cell charge panel has been placed in direct sunlight.
Light is not as bright as normal	Battery charge may be low. Turn the power switch to the ON position and charge the battery for two (2) sunny days, ensuring the solar cell charge panel has been placed in direct sunlight.