

Distributed By: Metal Fusion, Inc. 712 St. George Ave. Jefferson LA 70121 (504)736-0201 www.kingkooker.com


Model# 5500 -Oyster Opener

Read and Understand the following directions before using this product.

This product should be used by adults and only in accordance with the directions below. If you have any questions, please contact Metal Fusion, Inc. at 1-800-783-3885 between the hours of 7:00 AM and 3:30 PM CST.

Parts:

- (1) Board
- (1) Base
- (1) Lever Bar
- (2) Bolts
- (2) Nuts
- (4) Washers



Assembly Instructions:

- 1. Place the base of the oyster opener over the end of the board with two holes. Align the holes on the sides of the base with the holes on the board.
- 2. Insert each washer on a bolt and insert one bolt through each of the holes in the board.
- 3. Place another washer on the top side of each bolt after it is through the board and then tighten a nut onto each bolt.
- 4. Loosen the bolt running through the top of the oyster opener base and insert it through the hole in the top of the oyster opener arm with the point facing down. Wrench tighten.

Directions for Use:

- 1. Place the oyster opener on a sturdy surface.
- 2. Wear leather palm gloves for safety.
- 3. Raise the lever bar and place the oyster on the board hinge up, below the point of the lever.
- 4. Pull down slowly on the lever bar so that the point goes into the hinge of the oyster.

Warning: Make sure hands are clear of the point before pulling lever bar down.

- 5. When the oyster is opened, raise the bar and remove the oyster from the opener. Using an oyster knife, carefully femove the oyster from the shell. Make sure all debris or hard particles are removed from the oyster.
- 6. Maintenance of the oyster opener: Wash thoroughly and dry before storing.

Warnings:

This appliance is not for the use of children and children should be kept away from this appliance at all times. The use of alcohol, prescription, or non-prescription drugs may impair your ability to properly assemble or safely operate this appliance. Do NOT assemble or operate this appliance if using alcohol, prescription, or non-prescription drugs.

Eating raw oysters may cause severe illness and even death in persons who have liver disease (for example, alcoholic cirrhosis), cancer or other chronic illnesses that weaken the immune system. If you should become ill, you should seek immediate medical attention. If you are unsure you are at risk, you should consult your physician before consuming raw oysters.