

Includes one 40 bu. 48 cu. ft. Leaf Collection Bag.

Product Compatibility

Fits 2 and most 3 bag collection systems. Bag opening is 114 in. in circumference.

WARNING: This bag is not intended to completely replace the bags/baskets on your collection system. Leaf bags are designed for leaf collection only.



Installation Instructions

1. Prepare machine for installation by removing the bags from your mower's grass catcher/material collection system
2. Place Bag over chute and pull draw strings to secure bag to the hopper.

NOTE: If your chute enters the front of the hood, bag can be installed over or under the hood. If your chute that enters the hood from the side, install the bag underneath hood for more security.

3. Collect leaves until bag is filled.

NOTE: If bag is not filling completely or evenly, shake bag to move leaves towards the closed end. This will improve airflow.

4. Once full loosen draw strings to remove and empty bag

Lawn Tractor Leaf Bag by Superior Tech
877-530-9084
sales@Lawntractorleafbag.com
Form # LTLB-01 08 /19

Practice Safe Maintenance

1. Disengage mower blades and set parking brake before installing, adjusting, or removing leaf bag.
2. Always follow safety recommendations from your mowers manufacturer.
3. Avoid reversing. Reversing can result in damage to bag and tractor/mower. Bag may get lodged in tires or contact rear exhaust.
4. If the bag is too heavy or too large to handle in tight spaces, tie off a small portion at the end of the bag to resize.
5. If your bag accidentally rips or gets a hole in it, sew it, tape it, or use an iron-on patch to close it as soon as possible.
6. To clean your bag, you can hose it off and then hang it up to dry.

Warranty

Lawn Tractor Leaf Bag products are guaranteed to be free from defects in material and/or workmanship and to perform as advertised when properly assembled, installed, used, and maintained in accordance with written instructions. Failure to adhere to this will void the warranty. Lawn tractor Leaf Bag will not be responsible for labor, loss, or consequential damage of any kind or character caused by defective parts, or for charges incurred in the replacement or repair of defective parts. Lawn Tractor Leaf Bag reserves the right to request photos or return of damaged/defective parts. To submit a claim, please have your original purchase date and a copy of your receipt.

Warranty Period

Lawn tractor Leaf Bag products are warranted for a period of 1 (one) year after the purchase date. This product is warranted by Lawn tractor Leaf Bag to the original purchaser/customer against defects in material and workmanship under normal operating conditions.