




Model: EX8PEN2424
24"H Pet Exercise Play Pen
(8 Panels)

Packing List



Folded Exercise Pen (8 connected panels)

1 set



Closing Clamp

1 pc




Carabiners

3 pcs



Corner Retainers

8 pcs



Fastening Stakes

8 pcs

Assembly Manual

- 1 Check Parts** Make sure you have all the parts prior to assembly and try to get familiar with all the parts on the packing list. If an item is missing, please contact sales@rticorporation.com
- 2 Layout** (fig.1) Set exercise pen on the ground and unhook the closing clamp. Please note, when retracting the panels, reattach the closing clamp to secure the folded form.
- 3 Connect** (fig 2) Straighten and fully open the exercise pen, making both ends meet. Snap in all 3 carabiners at the top, middle, and bottom.
- 4 Shaping** (fig 3) Reshape the exercise pen to desired shape: Rectangle, square, octagon, etc.
- 5 Octagonal Retainers optional** (fig 4) Straighten the nearby panels as much as possible. From the top, apply the corner retainer with the slotted side facing the middle of two panels. Be to line up the corner retainer so that it intersects with both panels. Use all 8 corner retainers to maximize the stability of the pen when it is in the octagon shape. Alternatively, the corner retainers can be used as floor protectors by installing on the bottom of the pen.
- 6 Reinforce the Pen optional** (fig 5) When using the exercise pen outdoors on soft ground, the included fastening stakes can be pushed into the ground and hooked on the bottom of the kennel to reinforce the exercise pen and keep it upright and stable.



fig.1




fig.2




fig.3




fig.4




fig.5