



Ski/Snowboard Shelf with 10 Hooks (48")

Instruction Manual

contents:

- 4 - #8 1" black screws, #2 sq dr
- 6 - 0.25" 2.5" washer head screw, T25
- 1 - 48" L x 7.5" W wooden shelf
- 2 - brackets
- 4 - 2 prong hooks

Setting Up Your Ski/Snowboard Shelf with 10 Hooks (48")

CONFIRM THAT ALL PARTS ARE PRESENT BEFORE BEGINNING ASSEMBLY.

1. Items to note before starting assembly:
 - a. There are 2 brackets with hooks, one will be for the left side of the shelf, and the other for the right side. You will want to be sure that you fasten the correct bracket on the correct side. To do so, simply make sure the hooks face outwards, away from the shelf, on each side.
 - b. Additionally, you will see that the wooden shelf has 4, 2-prong hooks already attached to it; you will want to ensure that those hooks are facing outwards, away from the wall.
2. Secure the brackets to the wall.
 - a. Find the stud. You can put this shelf at whatever height you want, but if you want to hang skis or other long items from this shelf, you will need to measure that item and make sure you hang this shelf higher than that measurement. Put the long black screws in the holes of the brackets and fasten to the wall, ensuring the screws hit the studs.
 - b. Note: If the studs are not placed at 4', you can always adjust the length of the board as necessary, or you can use a longer board to fit your needs.
3. Attach the shelf to the brackets.
 - a. Center the wooden shelf between the metal brackets and put two of the short black screws in the holes underneath, fastening into the shelf.



Not to exceed 250 pounds.

happy with our products?

Please help us spread the word by leaving a review at: www.SHEDorize.com



SHEDorize

SHEDorize.com

(866) 548-1625

info@amishland.com