


# CANOPY WEIGHT BAGS

## WUY-080



### ⚠ CAUTION ⚠

1. Please read instructions COMPLETELY before use. If you have questions, please contact us via one of the methods mentioned at the top of page 1.
2. This product is classified as a canopy accessory and is intended to supplement a canopy's original anchoring system. If you know strong weather is predicted, remove the canopy fabric or take the unit down completely. Sunnydaze Decor does not guarantee this accessory will keep a canopy anchored during strong wind conditions.
3. Proper canopy use and anchoring is the RESPONSIBILITY OF THE OWNER. If your canopy is not securely anchored, strong winds can lift it and cause damage if it is blown over and/or away.
4. Sunnydaze Decor cannot be held responsible for damage resulting from improper installation and use. Refer to your original owners manual for proper canopy use and safety.
5. Damages caused by improper installation and weather elements are not considered a defect.


### ⚠ WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.


# INSTALLATION

## ! HELPFUL HINT

Put filling material into sealable plastic bags before placing them into the weight bag. This keeps the weight bags clean should they get wet or if the fabric starts to wear. Filling material and plastic bags are not included.



Place the bag on the foot of your canopy.  
Tightly wrap the hook and loop fastener strips around the canopy leg.



Fill both sides of the bag. Do not overfill.  
Press the hook and loop fastener strips on top of the bag together to close the bag.

## USE & CARE

**SUN EXPOSURE:** All fabrics will eventually fade and degrade from sun exposure. The less direct sunlight the bags are exposed to, the longer the life of fabric will be.

**STORAGE:** Store indoors, in a dry location during inclement weather and when it will not be used for an extended time. To prevent mold and mildew growth, ensure the bag is completely dry before storing.



HAND WASH ONLY



DO NOT USE BLEACH OR SOLVENTS



DO NOT TUMBLE DRY

**WASHING:** Use warm, soapy water and a cloth to scrub the fabric; dish soap works well. Thoroughly rinse all soap residue before air-drying the fabric. Never use bleach, harsh cleansers or abrasive materials to clean the fabric.

**DRYING:** Hang the bags and allow to thoroughly air dry. Allow air and light to hit as much of the fabric as possible — this will reduce the chance of mold and mildew.

Any modification to the product or failure to follow recommended care will void the product warranty.