

SAFETY INFORMATION

DANGER

DANGER - Immediate hazards which **WILL** result in severe personal injury or death

WARNING

WARNING - Hazards or unsafe practices which **COULD** result in severe personal injury or death

CAUTION

CAUTION - Hazards or unsafe practices which **COULD** result in minor personal injury

IMPORTANT SAFETY INSTRUCTIONS

WARNING

When using electrical appliances, basic safety precautions should be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USE.
2. Only use the air purifier as described in this manual.
3. To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
4. Remove all packaging material, including the plastic wrap over the filter before use.
5. If the adapter, its cord, or plug is damaged, it must be replaced by the manufacturer. Do not attempt to use a substitute adapter as it could result in hazard and/or injury. Contact customer service for further assistance.
6. Check the household voltage to ensure it matches the appliance's rated specification.
7. Do not let cord touch any hot surface and make sure that it does not hang over a table edge or counter.
8. Place air purifier on a firm, flat, level surface.
9. Do not use this product on wet surfaces. This air purifier is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate air purifier where it may fall into bathtub or other water container.
10. Avoid exposure to direct sunlight.

SAFETY INFORMATION

11. Close supervision is necessary when any appliance is used by or near children.
12. To reduce the risk of electric shock, do not remove screws. Do not attempt to repair or replace parts except for filters.
13. Unplug the appliance before cleaning it. Wipe it with a soft cloth.
14. Unplug the air purifier before removing the filter.
15. Do not immerse the appliance or the power cord in water or other liquids.
16. Do not use any detergents, glass or household cleaner, furniture polish, gasoline, paint thinner or other solvent to clean any part of the air purifier.
17. If you spill any liquid on the unit, it can cause serious damage. Switch it off and unplug immediately.
18. Do not block, cover or obstruct the air vents. Do not place anything on top of the unit.
19. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
20. **WARNING** - To reduce the risk of fire or electric shock, DO NOT use this air purifier with any solid-state speed control devices.
21. Do not use outdoors.

**READ AND SAVE THESE
INSTRUCTIONS
HOUSEHOLD USE ONLY**

SAFETY INFORMATION

WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience or knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

OPERATING CONDITION

The air purifier should be operated between a temperature range of 64°F (18°C) - 140°F (18°C) and a Relative Humidity under 90%.

NOTE: Unit performance may be affected when in use outside of these operating conditions.